





'62 AMERICAN VINTAGE STRATOCASTER / LEFT HAND 0100120



PICKGUARD ASSEMBLY



BRIDGE ASSEMBLY



'62 AMERICAN VINTAGE STRATOCASTER / LEFT HAND 0100120

REF.#	P/N	DESCRIPTION
1	0053816000	Neck, '62 Vintage Stratocaster, Upgrade, R/W
2	0027774000	Tuning Key, (1) Set
	0019312000	Bushing
	0011357000	Mounting Screw
3	0083675000	Bone Nut
4	0010389000	String Retainer
	0020423000	Spacer
	0011358000	Mounting Screw
5	0012252000	Truss Rod Adjustment Nut
6	0053815xxx	Body, '62 Strat, Upgrade, Sunburst
7	0019647000	Neck Mounting Plate
	0015636000	Mounting Screw
8	0012344000	Strap Buttom
	0016188000	Mounting Screw
9	0053817000	Pickguard, '62 Strat Vintage, Mint Green
	0015578000	Mounting Screw
10	0053812000	Pickup Assembly, '62 Vintage Strat, Upgrade (3)
	0015776000	Mounting Screw
	0036481000	Tubing, Latex Cut
11	0013446000	Control, 250k, Taper, (3)
	0016352000	Mounting Hex Nut
	0056790000	Lock Washer, Intl
12	0056145000	Knob, Volume, Aged White
13	0056144000	Knob, Tone, Aged White, (2)
14	0053290000	Switch, 3 Way Grigsby W/ Metal Roller
	0015776000	Mounting Screw
	0053765000	Knob, Aged White
15	0021022000	Capacitor, .1uf
16	0021956000	Output Jack
	0016352000	Mounting Hex Nut
	0016436000	Lock Washer, Intl
17	0010280090	Jack Ferrule
	0015578000	Mounting Screw
18	0027772000	Bridge Assembly, Vintage Strat
	0016170000	Mounting Screw
	0038962000	Bridge Block
	0019656000	Mounting Screw
	0010272100	Claw, Tremolo
	0015636000	Mounting Screw
	0031643000	Spring, Claw
	0053662000	Arm, Tremolo
	0053766000	Knob, Tremolo
19	0040851000	Bridge Plate
20	0019280000	Bridge Section, (6)
21	0015693000	Intonation Screw, (6)
	0019273000	Intonation Spring, 5&6
	0019281000	Intonation Spring, 1-4
22	0032782000	Height Adjustment Screw, 1&6
	0016071000	Height Adjustment Screw, 2-5
	0018531000	Height Adjusting Wrench
23	0012180000	Spring, Tremolo
24	0051504000	Back Plate, Tremolo, White
	0015578000	Mounting Screw

Body Part Number	
0053815500	3 Tone Sunburst

'62 AMERICAN VINTAGE STRATOCASTER / LEFT HAND 0100120

SWITCH & CONTROL FUNCTION

3 WAY SWITCH POSITION			
			← 3 WAY SWITCH POSITION
T1	T2	NO TONE	
			← NECK PICKUP
			← MIDDLE PICKUP
			← BRIDGE PICKUP
PICKUP IS OFF →			← PICKUP IS ON

