




AMERICAN DELUXE TELECASTER 0105500/5502




AMERICAN DELUXE TELECASTER 0105500/5502

CONTROL ASSEMBLY



BRIDGE ASSEMBLY



AMERICAN DELUXE TELECASTER 0105500/5502

REF.#	P/N	DESCRIPTION	REF.#	P/N	DESCRIPTION
1	0054043000	Neck, AM Deluxe Tele M/N	26	0036528000	Bridge Section, (6)
	0054042000	Neck, AM Deluxe Tele R/W	27	0031913000	Intonation Screw, 1&2
2	0021374000	Tuning Key, (1) Set		0029095000	Intonation Spring, 1&2
3	0083675000	Bone Nut	28	0017031000	Intonation Screw, 3-6
4	0054625000	String Retainer		0029094000	Intonation Spring, 3-6
	0021407000	Mounting Screw	29	0018027000	Height Adjust Screw, 2-5
5	0020810000	Truss Rod Adjustment Nut	30	0026780000	Height Adjust Screw, 1&6
	0023811000	Truss Rod Adjusting Wrench			
6	0054135XXX	Body, AM Dlx Tele Ash Wht. Binding			
	0054040XXX	Body, AM Dlx Tele Alder			
	0054041XXX	Body, AM Dlx Tele Ash Brn.Shl. Binding			
7	0054038000	Neck Mounting Plate			
	0021424000	Mounting Screw			
8	0031571000	Tilt Adjust Screw			
9	0021453000	Strap Button			
	0021422000	Mounting Screw			
	0020491000	Felt Washer, White			
	0019056000	Felt Washer, Black			
10	0054044000	Pickguard, AM Dlx Tele Mint Grn			
	0021407000	Mounting Screw			
	0048637000	Pickguard, AM Dlx Tele Brn Shl			
	0021407000	Mounting Screw			
11	0053660000	Pickup, N.F. Chrome			
	0050166000	Mounting Screw			
	0003941000	Tubing, Latex Cut			
12	0053352000	Pickup, N.F. Aged White			
	0048631000	Mounting Screw			
	0003648100	Tubing, Latex Cut			
13	0053661000	Pickup, Tele N.F. Bridge			
	0048631000	Mounting Screw			
	0036878000	Tubing, Latex Cut			
14	0019064000	Control, 250k			
	0016352000	Mounting Hex Nut			
	0016436000	Washer, Lock Intl.			
15	0050886000	Control, 250k, No Load			
	0016352000	Mounting Nut			
	0016436000	Washer, Lock Intl.			
16	0013359000	Knob, Knurled Chrome (2)			
	0028897001	Screw Set (2)			
17	0037408000	Switch, Mini			
	0021716000	Mounting Hex Nut			
	0021718000	Washer, Flat			
18	0037258000	Plate, Control			
	0021407000	Mounting Screw			
19	0053291000	Switch, Lever 5-Position			
	0018359000	Knob, Blk			
	0021413000	Mounting Screw			
20	0024832000	Capacitor, .022uF			
21	0021956000	Output Jack			
	0016352000	Mounting Nut			
	0016436000	Lock Washer			
22	0021452000	Ferrule, Jack			
23	0021429000	Retainer String , Chrome			
24	0054048000	Bridge Assy, Am. Dlx			
	0021373000	Mounting Screw			
	0018531000	Adjusting Wrench, Saddle Height			
25	0028184000	Bridge Plate, Am Std Tele			
	0021373000	Mounting Screw			

Body Part Number

0054040500	3-Tone Sunburst
0054040506	Black
0054040538	Crimson Transparent

0054041501	Blonde
------------	--------

0054135548	Teal Green Transparent
0054135594	Purple Transparent

AMERICAN DELUXE TELECASTER 0105500/5502

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION						
	5	4	3	2	1	← 5 WAY SWITCH POSITION
T O G G L E S W I T C H	B	NECK PICKUP	MIDDLE PICKUP	BRIDGE PICKUP		← NECK PICKUP
		NECK PICKUP	MIDDLE PICKUP	BRIDGE PICKUP		← MIDDLE PICKUP
		NECK PICKUP	MIDDLE PICKUP	BRIDGE PICKUP		← BRIDGE PICKUP
	A	NECK PICKUP	MIDDLE PICKUP	BRIDGE PICKUP		← NECK PICKUP
		NECK PICKUP	MIDDLE PICKUP	BRIDGE PICKUP		← MIDDLE PICKUP
		NECK PICKUP	MIDDLE PICKUP	BRIDGE PICKUP		← BRIDGE PICKUP
						← PICKUP IS ON
						← PICKUP IS OFF

