



60's TELECASTER 0131600




60's TELECASTER 0131600

CONTROL ASSEMBLY



BRIDGE ASSEMBLY



60's TELECASTER 0131600

REF.#	P/N	DESCRIPTION
1	0058381000	Neck, 60's Telecaster R/W
2	0047912000	Tuning Key, (1) Set
	0053020000	Bushing, Key
	0011357000	Mounting Screw
3	0083675000	Bone Nut
4	0010389000	String Retainer
	0020423000	Sapcer
	0011358000	Mounting Screw
5	0012252000	Truss Rod Adjustment Nut
6	0058380XXX	Body, 60's Telecaster, Alder
7	0018353000	Neck Mounting Plate
	0015636000	Mounting Screw
8	0012344000	Strap Button
	0015610000	Mounting Screw
9	0056077000	Pickguard, Tele, Aged White
	0015578000	Mounting Screw
10	0053678000	Pickup, Neck
	0016295000	Mounting Screw
	0039410000	Tubing, Latex Cut
11	0055216000	Pickup, Bridge
	0015800000	Mounting Screw
	0036878000	Tubing, Latex Cut
12	0019064000	Control, 250k (2)
	0016352000	Mounting Hex Nut
	0016436000	Washer, Lock Intl.
13	0013359000	Knob, Knurled Chrome (2)
	0028897001	Screw Set (2)
14	0040778000	Plate, Control
	0016188000	Mounting Screw
15	0053290000	Switch, Lever 3-Position
	0019448000	Knob, Black
	0021413000	Mounting Screw
16	0015552000	Capacitor, .05uF
17	0047329000	Output Jack
	0016352000	Mounting Hex Nut
	0016436000	Washer, Lock Intl.
18	0021452000	Ferrule, Jack
	0010355000	Retainer, Jack
	0016352000	Mounting Hex Nut
19	0058384000	Bridge Assy
	0016188000	Mounting Screw
20	0054162000	Bridge Plate
21	0056038000	Bridge Section, (3)
22	0015834000	Intonation Screw, (3)
	0018689000	Intonation Spring, 1-3
23	0016105000	Height Adjust Screw, (6)
24	0012112000	String Retainer, Ferrule

Body Part Number

0058380505	Olympic White
0058380506	Black
0058380509	Candy Apple Red

60's TELECASTER 0131600
SWITCH & CONTROL FUNCTION

