



# DELUXE ACTIVE JAZZ BASS 0136700




# DELUXE ACTIVE JAZZ BASS 0136700


## CONTROL ASSEMBLY



## BRIDGE ASSEMBLY



**DETAIL A**



## DELUXE ACTIVE JAZZ BASS 0136700

REF.#	P/N	DESCRIPTION	REF.#	P/N	DESCRIPTION
1	0053230000	Neck, Deluxe Active J-Bass, Mex., R/W	24	0040798000	Bridge Ass'y, Bass, Mexico
2	0036400000	Tuning Key, (1) Set		0015610000	Mounting Screw
	0051532000	Bushing	25	0040799000	Bridge Plate, Jazz / Precision Bass
	0011357000	Mounting Screw	26	0007706000	Bridge Section (4)
3	0083675000	Bone Nut	27	0015842000	Intonation Screw (4)
4	0021427000	String Retainer		0018689000	Intonation Spring (4)
	0015578000	Mounting Screw	28	0040800000	Height Adjustment Screw (8)
5	0038454000	Truss Rod Adjustment Nut			
	0021109000	Truss Adjusting Wrench			
6	0053228xxx	Body, Deluxe Active J-Bass, Mexico, Solid Paint			
	0053229xxx	Body, Deluxe J-Bass, Mexico, Sunburst			
7	0018353000	Neck Mounting Plate			
	0015636000	Mounting Screw			
8	0012344000	Strap Button			
	0015610000	Mounting Screw			
	0001905600	Felt Washer, Black			
	0020491000	Felt Washer, White			
9	0053248002	Pickguard, Deluxe Active J-Bass, Shell			
	0015578000	Mounting Screw			
10	0049447000	Pickup, Jazz Bass Deluxe, Neck			
	0027035000	Mounting Screw			
	0017333000	Weatherstrip, Rubber			
11	0049446000	Pickup, Jazz Bass Deluxe, Bridge			
	0027035000	Mounting Screw			
	0017333000	Weatherstrip, Rubber			
12	0040780000	Control, Plate			
13	0054137000	Circuit Board			
	0049440003	Control, 25K,			
	0016352000	Mounting Hex Nut			
	0050161000	Lock Washer, Intl.			
14	0049441000	Control, 250K, Pan Pot			
	0016352000	Mounting Hex Nut			
	0016436000	Lock Washer, Intl.			
15	0053736000	Control, 100K, B, Tocos			
	0016352000	Mounting Hex Nut			
	0016436000	Lock Washer, Intl.			
16	0049443000	Control, 100K, B, CTS			
	0016352000	Mounting Hex Nut			
	0016436000	Lock Washer, Intl.			
17	0012869000	Solder Lug			
	0015116000	Mounting Screw			
18	0019455000	Knob, Skirted, Large, Black (2)			
19	0049412000	Knob, Lower, Black			
	0049411000	Knob, Upper, Black			
20	0019513000	Knob, Small, Black			
21	0039432000	Output Jack			
	0016352000	Mounting Hex Nut			
	0016436000	Lock Washer, Intl.			
	0031153000	Washer, Flat			
22	0050100000	Jack Ferrule			
	0015578000	Mounting Screw			
23	0049705000	Cover, Battery, Black			
	0017405000	Battery, 9 Volt			
	0018556000	Weatherstrip, Foam Block			
	0030688000	Insert,Cover			
	0030654000	Mounting Screw			

Body Part Number	
0053229532	Brown Sunburst
0053228506	Black
0053228509	Candy Apple Red
0053228580	Arctic White

# DELUXE ACTIVE JAZZ BASS 0136700

## CONTROL FUNCTION

