


SHOWMASTER QMT HH 0263280/552

WIRING DIAGRAM



SHOWMASTER QMT HH 0263280/552

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
					← 5WAY SWITCH POSITION
V&T	V&T	V&T	V&T	V&T	← TONE CONTROL
					← NECK PICKUP
					← BRIDGE PICKUP
	← PICKUP IS ON				← PICKUP IS PARALLEL CONNECTED
					← PICKUP IS OFF

